

(TOP RIGHT FRONT OF ENGINE) EVAPORATIVE EMISSION PURGE SOLENOID VALVE

(RIGHT SIDE OF OIL PAN) ENGINE OIL LEVEL SWITCH

INSTRUMENT CLUSTER

(TOP OF FUEL TANK) FUEL TANK PRESSURE SENSOR

ENGINE CONTROL MODULE (LEFT FRONT OF ENGINE COMP)

562588