



(EXHAUST, DOWNSTREAM OF  
OF CATALYTIC CONVERTER)  
HEATED OXYGEN  
SENSOR 2




(EXHAUST  
MANIFOLD)  
HEATED OXYGEN  
SENSOR 1



(RIGHT SIDE  
OF ENGINE)  
EVAPORATIVE  
EMISSION PURGE  
SOLENOID VALVE



(RIGHT SIDE  
OF FUEL TANK)  
EVAPORATIVE  
EMISSION VENT  
SOLENOID VALVE



EXHAUST CAMSHAFT  
POSITION  
ACTUATOR  
SOLENOID VALVE  
(LEFT FRONT  
OF ENGINE)

INTAKE CAMSHAFT POSITION  
ACTUATOR  
SOLENOID VALVE  
(RIGHT FRONT  
OF ENGINE)

ENGINE COOLANT  
TEMPERATURE (ECT)  
SENSOR 2  
(REAR OF  
ENGINE BLOCK)

MULTIFUNCTION INTAKE AIR SENSOR  
(AFTER AIR CLEANER)

G104  
(REAR OF  
CYLINDER  
BANK)

ACCELERATOR PEDAL  
POSITION (APP) SENSOR  
(TOP OF ACCELERATOR  
PEDAL ASSEMBLY)